

Disinfection instruction for Winmate products

1. Products affected:
 - 1.1. All Tablet PC/ PDA/ Portable Devices
2. Precautions:
 - 2.1. Please make sure that **all I/O doors are closed**
 - 2.2. Please make sure the **batteries are inserted**
 - 2.3. Please make sure the product **is not running and not connected to power** in any way
3. Materials needed
 - 3.1. Please use **Isopropyl Alcohol 70%**
 - 3.2. Please use a **spray bottle** to apply a mist of disinfection solution in a fine layer
 - 3.3. Please use **an industrial grade paper towel**, that is stable when wet and does not make lint or fluff (paper left over)
 - 3.4. Please use **one way silicone gloves & face mask** when disinfecting the devices to avoid any cross contamination
4. Cleaning
 - 4.1. Please spray the device from all sides and wipe the solution off with the paper towel, especially in the edges and corners
 - 4.2. **Do not re-use the paper towel** for the next devices to avoid cross contamination
 - 4.3. Let the device stand for half an hour to let the alcohol residue to evaporate, before using the device again.
5. Discard the Facemask, towels used and gloves appropriately as **medical waste**

Some Examples:

